

TROUBLESHOOTING WITH VOLT OHMMETER

HINT: Because the following troubleshooting procedures are designed for inspection of each separate system, the actual troubleshooting procedure may vary somewhat.


However, please refer to these procedures and perform actual troubleshooting, conforming to the inspection methods described.

For example, it is better to first make a simple check of the fuses, fusible links and connecting condition of the connectors before making your inspection according to the procedures listed.

The following troubleshooting procedures are based on the supposition that the trouble lies in either a short or open circuit in a component outside the -computer or a short circuit within the computer. If engine trouble occurs even though proper operating voltage is detected in the computer connector, then the engine control module is faulty and should be replaced.


FUSES AND FUSIBLE LINK LOCATION

EG10H-02



MFI SYSTEM CHECK PROCEDURE

8810J-02



HINT:

- Perform all voltage measurements with the connectors connected.
- Verify that the battery voltage is 11 V or more when the ignition switch is in "ON" position. Using a voltmeter with high impedance (110 kΩ/V minimum), measure the voltage at each terminal of the wiring connectors.


8810K-03

Engine Control Module (ECM) Terminals

Symbol	Terminal Name	Symbol	Terminal Name	Symbol	Terminal Name
NE	DISTRIBUTOR	VC	VOLUME AIR FLOW METER	BATT	BATTERY B+
G⊖	DISTRIBUTOR	E2	SENSOR GROUND	+ B	EFI MAIN RELAY
G1	DISTRIBUTOR	VS	VOLUME AIR FLOW METER		-
G2	DISTRIBUTOR	⁵ OX+	HEATED OXYGEN SENSOR	+ B1	EFI MAIN RELAY
IGF	IGNITER	THA	INTAKE AIR TEMP. SENSOR		-
*1 SPD2	VEHICLE SPEED SENSOR	VTA	THROTTLE POSITION SENSOR		-
*2 S4	TCM SOLENOID	.THW	ENGINE COOLANT TEMP. SENSOR	*1 OIL	A/T OIL TEMP. WARNING LIGHT
*1 L	PARK/NEUTRAL POSITION SWITCH	IDL	THROTTLE POSITION SENSOR	E21	SENSOR GROUND
*1 S3	TCM SOLENOID	KNK	KNOCK SENSOR	W	MALFUNCTION INDICATOR LAMP
*1 2	PARK/NEUTRAL POSITION SWITCH	*3 THG	EGR GAS TEMP. SENSOR	*1 OD2	O/D MAIN SWITCH
*1 S2	TCM SOLENOID	OX	HEATED OXYGEN SENSOR	STP	STOP LIGHT SWITCH
*1 N	PARK/NEUTRAL POSITION SWITCH	*2 TH02	T/F FLUID TEMP. SENSOR	SEL2	-
*1 S1	TCM SOLENOID	² TH01	4WD OIL TEMP. SENSOR	*1 P	PATTERN SELECT SWITCH
*2 L4	TRANSFER POSITION SWITCH	TE1	D LC1	SEL1	-
FPU	VSV (for EG R)	VF	D LC 1	*4 4WD	4WD SWITCH
IGT	IGNITER	TE2	DLC1	ACT	A/C AMPLIFIER
STJ	COLD START INJECTOR		-	SPD1	VEHICLE SPEED SENSOR
EGR	VSV (for EG R)		-	*1 DG	DLC1
HT	HEATED OXYGEN SENSOR		-	A/C	A/C MAGNET SWITCH
AS	VSV (for PAIR)		-	*1 OD1	CRUISE CONTROL ECU
E1	ENGINE GROUND		-	STA	STARTER SWITCH
ACV	VSV (for A/C)		-		-
#10	INJECTOR		-		-
#20	INJECTOR		-		-
E01	ENGINE GROUND		-		-
E02	ENGINE GROUND		-		-

*1: A/T only *2: 4WD A/T only *3: California only *3: California and C & C *4: 4WD only *5: California 2WD only

Engine Control Module (ECM) Terminals




FI2796


Engine Control Module (ECM) Wiring Connectors Voltage

No.	Terminals	Condition		STD voltage	See page
1	BATT - E1	-		9 - 14	EG2-186
	+ B - E1	Ignition SW ON			
	+ B1 - E2				
2	IDL - E2 (E21)	Ignition SW ON	Throttle valve open	9 - 14	EG2-188
	VC - E2 (E21)		-	4.5 - 5.5	
	VTA - E2 (E21)		Throttle valve fully closed (Throttle opener must be cancelled first)	0.3 - 0.8	
			Throttle valve fully open	3.2 - 4.9	
3	VC - E2 (E21)	Ignition SW ON	-	4.5 - 5.5	EG2-190
	VS - E2 (E21)		Measuring plate fully closed	4.0 - 5.5	
			Measuring plate fully open	0.2 - 0.5	
	VS - E2 (E21)	Idling	2.3 - 2.8		
		3,000 rpm	0.3 - 1.0		
THA - E2 (E21)	Ignition SW ON	Intake air temperature 20°C (68°F)	0.5 - 3.4		
4	THW - E2 (E21)	Ignition SW ON	Engine coolant temperature 80°C (176°F)	0.2 - 1.0	EG2-192
5	STA - E1	Cranking		6 V or more	EG2-193
6	#10 - E01 #20 - E02	Ignition SW ON		9 - 14	EG2-194
7	IGT - E1	Idling		Pulse generation	EG2-195
8	W - E1	No trouble (malfunction indicator lamp off) and engine running		9 - 14	EG2-196
9	STJ - E1	Cranking	Engine coolant temperature 80°C (176°F)	6 V or more	EG2-197
10	STP - E1	Stop light switch ON		7.5 - 14	EG2-198


Engine Control Module (ECM) Terminals




No.	Terminals	Trouble	Condition	STD Voltage
1	BATT - E1	No voltage	-	9 - 14 V
	+ B - E1			
	+ B1 - E1			
			Ignition switch 4N	




FI5974



FI3714







FI2754



FI3502

• BATT- E1





• +B (+B1) -E1

(1) There is no voltage between ECM terminals + B (+ B1) and E1. (IG SW ON) .

(2) Check that there is voltage between ECM terminal + B (+ B1) and body ground. (IG SW ON)

NO OK

(3) Check wiring between ECM terminal E1 and body ground.

OK

SAD

Try another ECM.

Repair or replace.

Check fuse, fusible link and ignition switch.

BAD

Repair or replace.

OK

Check EF 1 main relay.

BAD

Replace.

OK

Check wiring between E F I main relay and battery.

BAD

Repair or replace.


OK

Check wiring between EFI main relay and ECM terminal + B (+B1).

BAD


Repair or replace.

No.	Terminals	Trouble	Condition	STD Voltage	
2	IDL - E2 (E21)	No voltage	Ignition switch O N	Throttle valve open	9 - 14 V
	VC - E2 (E21)			-	4.5 - 5.5 V
	VTA - E2 (E21)			Throttle valve fully closed (Throttle opener must be cancelled first)	0.3 - 0.8 V
				Throttle valve fully open	3.2 - 4.9 V




F13877


• IDL - E2 (E21)




F13899








F13898




P02969







• VC - E2 (E21)




• VTA - E2 (E21)




No.	Terminals	Trouble	Condition	STD Voltage	
3	VC - E2 (E21)	No voltage	Ignition SW ON	-	4.5 - 5.5 V
	VS - E2 (E21)			Measuring plate fully dosed	4.0 - 5.5 V
				Measuring plate fully open	0.2 - 0.5 V
	THA - E2 (E21)		Idling	2.3 - 2.8 V	
			IG SW ON	Intake air temperature 20°C (68°F)	0.5 - 3.4 V




F16069



F13900



F13898



F13928

• VC - E2 (E21)

(1) There is no voltage between ECM terminals VC and E2 (E21). (IG SW ON)

(2) Check that there is voltage between ECM terminal + B (+ 131) and body ground. (IG SW ON)

(3) Check volume air flow meter.






Refer to No. 1.

BAD
Replace or repair volume air flow meter.


OK
Check wiring between ECM and volume air flow meter.

OK
Try another ECM.


BAD
Replace or repair wiring.




• VS - E2 (E21)




• THA - E2 (E21)



No.	Terminals	Trouble	Condition		STD Voltage
4	THW - E2 (E21)	No voltage	Ignition switch ON	Engine coolant temperature 80°C (176°F)	0.2 - 1.0 V



FI5971



FI3906


(1) There is no voltage between ECM terminals THW and E2 (E21). (IG SW ON)

(2) Check that there is voltage between ECM terminal +B (+ B1) and body ground. (IG SW ON)

OK

NO

Refer to No. 1.



FI3898

Check wiring between ECM terminal E1 and body ground.

OK

BAD

(3) Check engine coolant temp. sensor.

Repair or replace.

BAD

OK

Replace engine coolant temp. sensor.


Check wiring between ECM and engine coolant temp. sensor.

OK

BAD


Try another ECM.

Repair or replace.




P03049


No.	Terminals	Trouble	Condition	STD Voltage
5	STA - E1	No voltage	Cranking	6 V or more




P03018




FI3499




FI3502




FI0336




No.	Terminals	Trouble	Condition	STD Voltage
6	# 10 - E01 # 20 - E02	No voltage	Ignition switch ON	9 - 14 V




PO2877




F13510




F13509




F13183




No.	Terminals	Trouble	Condition	STD Voltage
7	IGT - E1	No voltage	Idling	Pulse generation




FI5978



FI3522








FI3506




FI3502

```


    graph TD
      A["(1) There is no voltage between ECM terminals IGT and E1. (idling)"] --> B["(2) Check that there is voltage between ECM terminal IGT and body ground. (idling)"]
      B -- OK --> C["(3) Check wiring between ECM terminal E1 and body ground."]
      B -- BAD --> D["Refer to No. 1."]
      C -- OK --> D
      C -- BAD --> E["Repair or replace."]
      D -- OK --> F["Check wiring between igniter and distributor."]
      D -- BAD --> E
      F -- OK --> G["Check distributor."]
      F -- BAD --> E
      G -- OK --> H["Check wiring between ECM and igniter."]
      G -- BAD --> E
      H -- OK --> I["Check igniter."]
      H -- BAD --> E
      I -- OK --> J["Try another ECM."]
      I -- BAD --> E
  
```




No.	Terminals	Trouble	Condition		STD Voltage
9	STJ - E1	No voltage	Cranking	Engine coolant temperature 80° (176° F)	6 V or more




FI3893




FI3523









FI3898



P10005











F16035

(California 2WD only)




F16036




*Rich malfunction only


(California Vehicles and C & C)




FI3895



FI3907



FI3898



FI2674

