



# MOULDING

## Windshield Moulding

### COMPONENTS



N03041




B03231

## REMOVAL OF WINDSHIELD MOULDING

### LOCATION OF CLIPS AND FASTENER

- For vehicles in the table below which have black moulding, refer to diagram type 1.
- For other vehicles which have black or metallic moulding, refer to diagram Type 11.
- However, if all clips and fasteners are replaced, either diagram Type I or Type 11 may be referred to.




B03229 B03229

### Type I Applicable Models

Frame No.	Vehicle Code	Frame No.	Vehicle Code
0000001 ~ 1999999	VZN 100, VZN 105	0000001 ~ 6999999	RN101, RN106
0000001 ~ 4999999	RN80, RN85, RN90 VZN80, VZN85, VZN90, VZN 110	0000001 ~ 9999999	VZN95
		6000000 ~ 9999999	VZN100, VZN105
0000001 ~ 5999999	RN110	-	-

**1. REMOVE WIPER ARMS**  
**2. REMOVE COWL LOUVER AND WEATHERSTRIP**  
**3. REMOVE LOWER MOULDING WITH LOWER JOINT COVERS**


- (a) Remove five screws from the clips.  
 (b) Pry up a scraper to loosen the clips from the body.  
 HINT: Tape the scraper tip before use.  
 (c) Remove the moulding with lower joint covers and clips.



BO3674

**4. REMOVE SIDE MOULDING WITH UPPER JOINT COVERS**


- (a) Install the tip of a scraper between the body and moulding.  
 HINT: Tape the scraper tip before use.  
 (b) Pry up the scraper to loosen the moulding from the claws of the clips and fasteners.  
 (c) Remove the moulding with upper joint covers.



BO3299

**5. REMOVE UPPER MOULDING**




- (a) Using a knife, cut off the upper moulding as shown.  
 (b) Cut off the old adhesive around the upper moulding installation area.  
**NOTICE: Do not damage the body and glass.**



U0213

**REPLACEMENT OF FASTENER**  
**REPLACE FASTENER**

- (a) Remove the damaged fastener.  
 (b) Cut off the old adhesive around the fastener installation area.  
**NOTICE: Be carefully not to damage the body.**  
 (c) Clean the installation area.  
 (d) Install new fastener onto the body.



## INSTALLATION OF WINDSHIELD MOULDING

### 1. INSTALL CLIP INTO MOULDING

(See page [BO-13](#))

Install the clip to the appropriate place on the moulding.

### 2. APPLY ADHESIVE AT CLIP INSTALLATION AREA

(a) Cut out the old adhesive around the clip installation area.

**NOTICE: Do not damage the body and fastener.**

(b) Apply adhesive at the clip installation area so water does not collect there.

### 3. APPLY ADHESIVE AT UPPER MOULDING INSTALLATION AREA

### 4. INSTALL NEW UPPER MOULDING

Place the moulding onto the body and tap it by hand.

### 5. INSTALL SIDE MOULDING WITH UPPER JOINT COVERS

(a) Place the moulding with upper joint covers onto the body.

(b) Tap the moulding by hand to install it.

(c) Pry up the clips on the body side, and install them to the moulding.

### 6. INSTALL LOWER MOULDING WITH LOWER JOINT COVERS

(a) Place the moulding with lower joint covers onto the body.

(b) Align the clips of the moulding with the body holes, and push the moulding on the body.


### 7. INSTALL COWL LOUVER AND WEATHERSTRIP

(See page [BO-13](#))

### 8. INSTALL WIPER ARMS

(See page [BO-13](#))

## Wheel Arch Moulding COMPONENTS



B03230

### REPLACEMENT OF FRONT WHEEL ARCH MOULDING

#### 1. REMOVE FRONT WHEEL ARCH MOULDING

- (a) Remove five screws.
- (b) Using a screwdriver, pry up the wheel arch moulding, and remove it.

HINT: Tape the screwdriver tip before use.

#### 2. INSTALL FRONT WHEEL ARCH MOULDING

- (a) Tap the wheel arch moulding by hand to install it.
- (b) Install five screws.

### REPLACEMENT OF REAR WHEEL ARCH MOULDING

#### 1. REMOVE REAR WHEEL ARCH MOULDING

- (a) Remove six screws.
- (b) Using a screwdriver, pry up the wheel arch moulding, and remove it.

HINT: Tape the screwdriver tip before use.

#### 2. INSTALL REAR WHEEL ARCH MOULDING

- (a) Tap the wheel arch moulding by hand to install it.
- (b) Install six screws.